

ECON SERIES PUMP HEAD PARTS



DIAGRAM	PART NUMBER	UM	DESCRIPTION	Works with Econ Pumps
①	EC30A-2	2-PK	Pump Tube A, Ferrules 1/4"	T
	EC30B-2	2-PK	Pump Tube B, Ferrules 1/4"	T
	EC30C-2	2-PK	Pump Tube C, Ferrules 1/4"	T
	EC30F-2	2-PK	Pump Tube F, Ferrules 1/4"	FP / T / Integrator™ / LD
	EC30G-2	2-PK	Pump Tube G, Ferrules 1/4"	FP / T / Integrator™
	EC30H-2	2-PK	Pump Tube H, Ferrules 1/4"	FP / Stennicator / Integrator™ / T
	EC30M-2	2-PK	Pump Tube M, Ferrules 1/4"	LD
②	EC355	EA	Pump Head Cover	All Econ Pumps
③	EC350	EA	White Roller Assembly	See chart below for model, tube and roller assembly combination
④	EC351	EA	Black Roller Assembly	

NOTE: For check valves, injection parts, suction/discharge tubing and miscellaneous parts reference pages 48-50.

ECON PUMP TUBE GUIDE

Pressure	Econ Series	Tube/Roller Assembly
25 psi (1.7 bar)	Econ T	A/White B/White C/White
80 psi (5.5 bar) check valve required	Econ FP, Econ Integrator™, Econ T	F/White G/Black
	Econ FP, Econ Integrator™, Econ T, Stennicator	H/Black
	Econ LD	F/White M/White

Refer to output chart to match tube & pump model.